

Tuning JESS 505 Mainsail BM Mast M2

Spreaders: 420 mm / maybe 415mm in over 18kn Sweptback 150mm - = loose 0 = just on + = tight ++ = very tight

Windstrength Bft and knots	very light, crew inside boat 0,5 -1 / 3-5kn	both on seattank 1-2 5-8kn	2-3 8-10kn	3-4 11-14kn	5 15-18	6 20+
Mastrake	7,88	7,87-7,86	7,80-7,75	7,75-7,68	7,68-7,60	7,60 and lower
Shrouds	+	- to 0	0	+	+ to ++	++
Mastcontroller	up for prebend	neutral	neutral /1cm down	2cm down	3cm down	3-4cm down
Jib in/out	46,5 /47	47/48	50	55	55-60	65 to all way out
Jibblock up / down - watch leach	totally loose /up	Still fairly loose	on / controll leach	+ means more down	++	++
Shroud base car	foreward -5cm	neutral 2,61m	neutral	+5 cm	+5 bis +7cm	+ 7 bis +10cm
Vang	Loose / taken off	loose , but no slack	+	++	+++	++++
Outhaul Main	+ means tight	ease -2 or 3cm	ease -1 or 2cm	+	++	++